



2021 SPORTAGE



VEHICLE FEATURE TIPS

Many of the Tips presented below are covered in greater detail in the Owner's Manual, Multimedia System Manuals, Features and Functions Guide, and Quick-Start Guide hangtag supplied with your new vehicle.

VOICE RECOGNITION¹ AND BLUETOOTH²

Using Voice Recognition

Improve Bluetooth® Voice Recognition (VR) performance by making a few simple changes to your phone contacts:

- Use full names (first and last names) vs. short or single-syllable names ("John Smith" vs. "Dad," "Smith Residence" vs. "Home").
- Avoid using special characters, emojis, and hyphenated names (@, &, #, /, -, *, +, etc.).
- Avoid using acronyms ("Emergency" vs. "ICE" or "In Case of Emergency") or words with all capital letters.
- Spell words completely; system will not recognize abbreviations ("Doctor Smith" vs. "Dr. Smith").
- Always wait for the beep before speaking any commands.
- When using VR to place a call, speak in a natural, moderate tone, with clear pronunciation. The system may have trouble recognizing commands if you speak too softly or too loudly.
- Open windows, sunroof, weather (wind/rain), or an A/C fan operating at higher speeds can interfere with VR accuracy.
- Your VR system may have difficulty understanding some accents or uncommon names.
- Press the talk button and say "Help" to get a list of available commands.

Pairing or Connecting Your Phone with Bluetooth®

- Press the Phone hard key (if equipped) or "Call" button on the steering wheel to begin the pairing process if no phone has previously been paired.
- During the pairing process, please make sure you accept all requests for phonebook download and future auto-connection on your phone.
- To pair a second phone or subsequent phones, reference the manuals and guides supplied with your Sportage as steps vary by radio.

- If you experience any issues with auto-connection, try the following:
 - Reboot your phone (turn the phone off and then on).
 - Update the phone operating system to the most recently released version.
 - Delete the phone from the list of Bluetooth® devices on the UVO display¹ and delete UVO from the list of Bluetooth® devices on your phone, and re-pair.
 - Ensure the phone has the Bluetooth® feature activated.
- If some contacts are not downloading to the UVO display, check to confirm that the contact has been entered correctly and that it has been stored under the categories (HOME, MOBILE, WORK, iPhone^{®3}) that are supported by the UVO display. Some contact categories (MAIN, PAGER, OTHER) may not be supported. If the number of contacts exceeds the maximum number allowed on the UVO display, contacts will be partially downloaded. Ensure that only the "phone contact list" is selected for contact download on your phone (not social media or email contact lists as these contacts may not download to the UVO display).
- Phone operating systems change frequently and some phones may have varying compatibility levels with the Bluetooth® system. For any questions regarding the features of your vehicle, please contact your preferred Kia dealer or contact Kia Consumer Assistance at 1-800-333-4542.

Other Bluetooth® Tips

- Bluetooth® reception is affected by carrier coverage and is dependent on the phone.
- If streaming audio through Bluetooth® from a device, ensure the listening volume on the device is turned up.

SMARTPHONE CONNECTIVITY¹



Apple CarPlay^{®3}

Your vehicle offers you effortless command of your compatible iPhone® when you connect through Apple CarPlay® on your UVO display. This will enable you to make calls, send hands-free texts, access your favorite music and apps, and get navigation help with Siri® voice control.

To connect Apple CarPlay, visit <https://youtu.be/N1FQ1VqDt4A>.



Android Auto^{™4}

Your vehicle allows you to connect to your compatible Android™ phone via Android Auto™ on your UVO display. Through this feature, you can access music, your phone's dialer, navigation help, and more with an intuitive interface and voice commands. You can even access your phone through your steering wheel controls.


To connect Android Auto, visit <https://youtu.be/QPV7y06-RJ4>.

FEATURE VIDEOS

To view a video on your mobile device, snap this QR Code or visit the listed website:
<https://www.youtube.com/KiaFeatureVideos>



SMART CRUISE CONTROL (SCC) WITH STOP & GO SYSTEM*⁵



The SCC with Stop & Go system is designed to help maintain a predetermined distance from vehicles detected ahead by automatically adjusting the driving speed as needed. When traffic is detected, the vehicle will slow down to maintain a set distance behind traffic without depressing the accelerator or brake pedal.

To set/adjust SCC speed:


- Press the CRUISE button **A** to turn the system ON. The CRUISE indicator will illuminate on the instrument cluster.
- Accelerate/decelerate to the desired speed.
- Press the (SET-) button **B** down to set speed. The SET indicator light will illuminate. The set speed and vehicle-to-vehicle distance will illuminate on the LCD screen.
- Press button **B** up or down to adjust the set speed.

To set the vehicle-to-vehicle distance **C**: Press the SCC button **D** on the steering wheel. The image on the LCD screen **E** will change when scrolling through the settings.


To cancel SCC operation: Press the CANCEL button **F** or press the brake pedal. The LCD screen will display a message that the SCC operation is cancelled **G**.

To turn SCC system OFF: Press the CRUISE button **A**. The CRUISE indicator on the instrument cluster will turn OFF.

LANE KEEPING ASSIST (LKA)⁵ / LANE DEPARTURE WARNING (LDW)⁵



The LKA system guides the driver to keep the vehicle within its lane and provides steering inputs when the vehicle is about to deviate from the lane.

With the Engine Start/Stop button in the ON position, press the LKA button **A** to turn the system ON or OFF. Once ON, the instrument cluster indicator  will illuminate white. It will remain white when the vehicle is traveling less than 40 mph and the system does not detect the lane markers. When the LKA system detects the lane markers and can assist the steering, the LKA icon will illuminate green.

If the LKA detects that you are moving outside of your lane, the system may give an audible warning and display an LDW alert on the instrument cluster. If the vehicle continues to move outside of the lane, the LKA can provide steering inputs, trying to prevent the vehicle from moving outside its lane.

Standard LKA is the operating mode by default when the LKA button is depressed to ON. To switch between modes (Standard LKA, Active LKA, and LDW), go to User Settings in the Instrument Cluster.


Active LKA provides more frequent steering inputs than standard LKA to keep the vehicle within lanes and provide steering inputs when the vehicle is about to deviate from the lane.

The LDW system alerts the driver when the system detects the vehicle leaving the lane. In this mode, the system will not provide steering inputs.

All systems will operate under the following conditions:

- The vehicle exceeds approximately 40 mph.
- The vehicle is between the lane markers.
- The LKA system recognizes the lane the vehicle is traveling in.
- LKA/LDW will return to its previous state when the ignition is cycled.

HIGH BEAM ASSIST (HBA)




- HBA is designed to automatically adjust the headlight range by switching between high and low beams based on light detected from other vehicles and road conditions.
- To enable HBA, toggle the light switch to the AUTO Light position **A** and turn on the high beams by pushing the lever away from you. The High Beam Assist indicator will illuminate.

Reminders:

- HBA will operate when vehicle speed exceeds 25 mph.

FORWARD COLLISION-AVOIDANCE ASSIST-PEDESTRIAN (FCA-PED)⁵ / FORWARD COLLISION WARNING (FCW)⁵



The FCA-Ped is designed to help alert the driver and, under certain conditions, apply emergency braking, when rapidly approaching a vehicle that is slowing down, braking, or stopped. Initially, the FCA-Ped provides FCW when it detects a potential collision with a vehicle in front, emitting an audible warning and visual alert on the instrument cluster **A**. The alert settings (Early, Normal, Late) can be adjusted or turned off in the user settings.


If the system detects that the collision risk has increased, the FCA-Ped can automatically apply the brakes to reduce your speed, potentially helping to minimize the effects of a possible collision. FCA-Ped can be turned ON in the User Settings menu on the Instrument Cluster display.

The FCA-Ped/FCW will become active when the:

- Engine Start/Stop button is ON.
- Vehicle is traveling more than 5 mph.
- Electronic Stability Control (ESC) is ON.

Warning: FCA-Ped and FCW are supplemental systems. Never intentionally attempt to activate or test the operation of the systems. Do not solely rely on the systems, and always drive safely.

SMART-POWER LIFTGATE OPERATION*



When the Smart Key fob is on your person and you are near the back of the vehicle, within close proximity, the hazard lights will blink and a chime will sound for about 3 seconds as an alert that the Smart-Power Liftgate is about to open.

Then the alert system will blink and chime two additional times before opening the Smart Power Liftgate.

The Smart-Power Liftgate feature is off by default. To enable the Smart-Power Liftgate, go to User Settings in the LCD Instrument Cluster modes.

Power Liftgate* Opening Height Adjustment: Adjust the liftgate height opening to suit the user's preference. The height setting of a fully opened liftgate can be adjusted by the following steps:

1. Position the liftgate manually to the preferred height.
2. Press the Power Liftgate Close button **A** for more than 3 seconds.
3. A system beep will sound twice indicating the height setting has been saved.


The liftgate will then open to the set height. To change the setting again, repeat steps 1-3.

KIA OWNER’S APP WITH UVO LINK*6



- Your cellphone and your vehicle have to be connected to a cellular network with a good wireless signal strength in order to use UVO. If these conditions are not met, remote commands will fail or will take a long time to execute.
- To use Remote Start or Remote Start with Climate Control feature, all doors, hood and trunk/lift-gate must be closed and locked. Remote Start or Remote Start with Climate Control feature will operate for about 10 minutes.
- The quickest way to obtain accurate vehicle status is by pressing a refresh button on your app or customer web portal.
- Activate Remote Start or Remote Start with Climate Control feature at least 10 minutes before you plan to get into the vehicle. This will allow vehicle interior to reach a desired temperature.
- In order to preserve vehicle battery, UVO will not work seven days after the ignition was last turned on. You will need to re-start your vehicle with a key fob in order to use UVO again.


ACCESSORY MODE WITH SMART KEY*



With standard key vehicles, you can turn the key to the accessory mode and utilize the electronic accessories without starting the vehicle. This is still possible with Smart Key-equipped vehicles. To do this, enter the vehicle with the Smart Key and push the ENGINE START/STOP button one time without depressing the brake pedal. This will put the vehicle in Accessory mode and ACC will illuminate in amber.

If the ENGINE START/STOP button is in the ACC position for more than 1 hour, the button is turned off automatically to help prevent battery discharge.

ECO MODE (ACTIVE ECO)




Eco Mode (Active Eco) is designed to help improve fuel economy by controlling several vehicle components. When activated, it optimizes drivetrain operations such as engine power and transmission to help improve fuel economy.

To turn ON, press the DRIVE MODE button and scroll through options until in ECO mode. The ECO indicator light **A** in the instrument cluster will illuminate green, indicating that Active ECO is operating. Active ECO will remain on even when the ignition is cycled.

To turn Active ECO OFF, press the DRIVE MODE button again and change to another mode.

TRIP MODES / TRIP COMPUTER




The Trip Computer is a driver information system that appears on the display when the ignition switch or the Engine Start/Stop button* is in the ON position.

To cycle through the different LCD Instrument Cluster modes, press the Mode button **A**.


When in Trip Computer mode, press the Move/Reset/OK button **B** to cycle through the screens. When displaying TRIP A or TRIP B screens, press and hold the OK button **B** to reset the Tripmeter to zero.

FUEL DOOR OPERATION





To open the fuel door, press the right edge of the fuel door. The fuel door will open only when the driver's door is unlocked.

Tighten the cap until it clicks one time; otherwise, the Check Engine Light may illuminate.



PARKING DISTANCE WARNING-FORWARD AND REVERSE*5



(Located below Gear Shift)

The Parking Distance Warning-FWD and Reverse is a supplemental system that is designed to assist the driver by chiming if certain objects are detected within the sensing area to the front and rear of the vehicle when moving forward or backing up.


The system is activated when the ignition is ON and the vehicle is in R (Reverse). To deactivate the system, press the Parking Distance Warning-FWD and Reverse button **A** (LED illuminated).

If the vehicle is moving at speeds over 3 mph, the system may not activate correctly.

When more than two objects are sensed at the same time, the closest one will be recognized first.


The Parking Distance Warning-FWD and Reverse is not a substitute for proper and safe backing-up procedures. Always drive safely and use caution when backing up. The Parking Distance Warning-FWD and Reverse may not detect every object in front of or behind the vehicle.

UNFASTENING CENTER SEATBELT



1. If the seatbelt is buckled, press the release button on the buckle.
2. To retract the 2nd-Row Center Seatbelt **A** into the headliner, press the "release button" on the buckle by inserting the seat belt tongue plate **B** in the small slot on the center buckle **C**.


SATELLITE RADIO RECEPTION



Satellite radio reception requires a direct line of sight with the satellite transmitting the radio signal. Tunnels, bridges, covered parking, mountainous terrain, tall buildings, heavy foliage, and other obstacles may momentarily interrupt the signal. This is normal operation, and reception will be restored within a few seconds in an open, unobstructed area.

The signal can become weak in some areas not covered by the satellite repeater network.

DOWNHILL BRAKE CONTROL (DBC)⁷




When driving down a steep slope, the DBC feature is designed to help make it easier to slowly and safely negotiate such terrain without having to use excessive brake pedal force.

The DBC select button **A** must be actively selected by depressing the button (button pictured left) prior to starting your descent. This system can be cancelled by pressing the DBC select button for a second time, or it will be automatically cancelled if the vehicle is accelerated to a speed above 38 MPH.

You may notice a slight spring-type noise or feel a mild vibration while the DBC is engaged and operating; however, this is completely normal.

USB PORTS AND USE OF CABLES



Vehicle may contain USB port(s) for transferring data or playing music from a compatible media device **A**, as well as USB port(s) designed for fast charging **B**.


Note: Devices will only charge while the vehicle is in ACC/ON/Start position.

If you encounter difficulty plugging in a compatible USB device, change the orientation of the device (may be upside down). Always use the USB charging cable that has been certified by the device manufacturer. Use of aftermarket cables is NOT recommended as they may impact functionality.

HILL START ASSIST CONTROL (HAC)⁷

The HAC system is designed to help prevent the vehicle from rolling backward on an inclined surface. This system is a supplemental system only, and does not replace the need to apply brakes depending on road and traffic conditions. HAC holds the braking pressure for 2 seconds after releasing the brake pedal. During the pressure-hold period, the system is designed to help provide the driver with enough time to press the accelerator pedal to drive off.

WIRELESS SMARTPHONE CHARGING SYSTEM^{*8}



1. System must be enabled in instrument cluster settings menu, and all doors must be closed for it to function.
2. Place a compatible smartphone on the center of the charging pad.
3. Indicator light **A** will change to amber once the wireless charging begins.
4. Once charging is complete, the amber light will change to green.


WIND BUFFETING

When driving with the rear windows lowered or the sunroof open, you may experience a wind buffeting or pulsation-type noise. This noise is normal and can be reduced or eliminated by partially lowering both front windows by an inch or more, or by partially closing the sunroof.

CONDENSATION INSIDE EXTERIOR VEHICLE LIGHTS

Your vehicle's exterior lights with clear lenses are vented to the atmosphere to release pressure as the air inside heats and cools. When humid/moist air enters the headlight/tail light, the moisture may condense on the lens surface and appear as fogging or water droplets. This is a normal condition and the moisture will evaporate when the lights are turned ON or when the temperature increases.

REAR VIEW MONITOR (RVM)⁵



The Rear View Monitor is a supplemental system that displays the view behind the vehicle through the audio head unit screens while the vehicle is in Reverse.

The RVM activates when the:

1. Engine Start/Stop* button is in the ON (Red light) position.
2. Gear Shift Lever is in the R (Reverse) position.

Reminders:

- During normal use and after inclement weather or washing, the rear camera may become dirty. Use a clean microfiber cloth to remove any dirt, debris, or spots that may have accumulated on the lens.
- While RVM is active, the volume will be lowered on all audio modes.



GIVE IT EVERYTHING

2021 Sportage SX Turbo shown on cover. Images or graphics are for illustrative purposes only and may not reflect actual feature or operation. See the Owner's Manual for more detailed information, limitations, and conditions. ¹If equipped. ²Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention, and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle. ³The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Kia is under license. A Bluetooth® enabled cell phone is required to use Bluetooth® Wireless Technology. ⁴Apple CarPlay, iPhone, and Siri are registered trademarks of Apple Inc., registered in the U.S. and other countries. ⁵Android and Android Auto are trademarks of Google LLC. Vehicle user interface is a product of Google and its terms and privacy statements apply. Requires the Android Auto app on Google Play and an Android compatible smartphone running Android™ 5.0 Lollipop or higher. Data plan rates apply. ⁶Driver-assist technologies are not substitutes for safe driving, and may not detect all objects surrounding vehicle. Always drive safely and use caution. ⁷Purchase/lease of certain 2021 and newer Kia vehicles with UVO link includes a complimentary 1-year subscription starting from new vehicle retail sale/lease date as recorded by the dealer. After your complimentary 1-year UVO link subscription expires, continued access to the full suite of UVO link services available on your Kia will require a paid subscription at the then-current subscription rate or your use of certain UVO link features may immediately terminate. Use of UVO is subject to agreement to the UVO Privacy Policy (available at owners.kia.com/us/en/privacy-policy.html) and Terms of Service (available at owners.kia.com/us/en/terms-of-service.html). UVO link is transferable to subsequent owner during the original UVO link service term. Only use UVO link when safe to do so. Kia Access with UVO link app is available from the Apple® App Store® or Google Play™ Store. Kia Motors America, Inc. reserves the right to change or discontinue UVO link at any time without prior notification or incurring any future obligation. Message and data rates may apply. Cellular and GPS coverage are required to use most features. UVO link features may vary by model, model year, and trim level. Features, specifications, and fees are subject to change. For more on details and limitations, visit www.kia.com or your authorized Kia dealer. Apple and App Store are registered trademarks of Apple Inc. Google and logos are trademarks of Google LLC. ⁸No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly. ⁹Charging system only works with select devices. Refer to the vehicle's Owner's Manual for warnings and instructions. ¹⁰Kia received the lowest rate of reported problems among mass market brands in the J.D. Power 2015–2020 U.S. Initial Quality Studies of new vehicle owners' experience with their own vehicle after 90 days of ownership. Tied in 2020. Visit jdpower.com/awards for more details.